

User Manual

Hybrid Storage Unit



EN Version : V1.6

Upower Electric Co.,Ltd

Content

1 Notes on this Manual	3
1.1 Scope	3
1.2 Target Group	3
1.3 Symbols Used	3
2 Safety	5
2.1 Important Safety Instructions	5
2.2 Explanation of Symbols	6
2.3 Emergency situation	7
3 Introduction	9
3.1 Scope of application	9
3.2 Product Model Description	
3.3 Datasheet	
4 Installation Instructions	15
4.1 Safety Tips	15
4.2 Packing List	15
4.3 Determine the installation method and location	
4.4 Preparations before installation	21
4.5 Installation steps for storage unit	22
5 Electrical Connections	
5.1 Electrical Interface Description	25
5.1.1 Inverter interface description	25
5.1.2 Battery interface description	
5.1.3 Base interface description	
5.2 System Wiring Schematic	27
5.3 Battery Wiring	27
5.3.1 Battery wiring (Battery does not expand)	
5.3.2 Grounding wire connection	
5.3.3 Side protection cover installation	
5.4 PV Input Wiring	
5.5 Grid/Load Wiring	
5.6 EV Charging wiring	
5.7 DRM Port Description	
5.8 CT Installation	
5.9 External AC Circuit Breaker and Residual Current Device	
5.10 Battery expansion	
6 Local Configuration	
6.1 Local Interface Introduction	40
6.2 Home Page	40
6.3 Detail Info Page	41
6.3.1 PV Info Page (only Hybrid)	41
6.3.2 Grid Info Page	41
6.3.3 Load Info Page	

6.3.4 Battery Info Page	
6.3.5 Inverter Info Page	
6.4 Fault Page	
6.5 Statistics Page	
6.6 Setting Page	
6.6.1 Brightness Setting Page	
6.6.2 Inverter Setting Page	45
6.6.3 Version Page	
6.6.4 Clear Page	
6.7 Start up the System	
6.8 Shut Down the System	
6.9 LED indication	55
6.9.1 Bat LED	
6.9.2 System status indicator	55
7 Fault Codes and Common troubleshooting	56
8 Battery Maintenance	57
8.1 Transportation	
8.2 Storage	
8.3 Cleanliness	

1 Notes on this Manual

1.1 Scope

This manual is an integral part of UHome Storage Unit.

Hybrid Inverter		
UHome-3K0L	UHome-3K6L	UHome-4K0L
UHome-4K6L UHome-5K0L UHome-6K0L		
UHome-8K0L		
Storage Battery		
ULB-5120MT		

This manual describes the assembly, installation, commissioning, maintenance and failure of the product. Please read it carefully before operating.

The manual is only for this batch of shipment.

1.2 Target Group

This manual is for qualified electricians. The tasks described in this manual only can be performed by qualified personnel.

1.3 Symbols Used

The following types of safety instructions and general information appear in this document as described below:

<u>À</u> Danger	Danger ! "Danger" indicates a hazardous situation which, if not avoided, will result in death or serious injury.
Marning	Warning! "Warning" indicates a hazardous situation which, if not avoided, could result in death or serious injury.

Caution	Caution ! "Caution" indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
13	Note ! "Note" provides tips that are valuable for the optimal operation of our product.

2 Safety

2.1 Important Safety Instructions

Danger!

- Electric shock and high voltage.
- Do not expose the storage unit to temperatures in excess of 45°C.
- Do not subject the storage unit to any strong force.
- Do not touch uninsulated cable termination.
- Do not soak the storage unit in water or expose it to moisture environment.

· Do not touch the case of the storage unit when it is wet in case of



- electric shock.Do not dispose of batteries in fire. The batteries may explode!
- Do not place the storage unit near a heat source, such as direct sunlight, a fireplace.
- Keep inflammable and explosive dangerous items or flames away from the storage unit.
- Do not charge or discharge damaged storage unit.
- Before performing any work on the storage unit, please disconnect the storage unit from all voltage sources as described in this document.

Warning!

- Installation, repair, recycling, and disposal of storage unit must be performed by qualified personnel in accordance with national and local standards and regulations.
- Risks of chemical burn electrolyte or toxic gases.
- Do not place heavy objects on the top of the system.
- Do not connect any un-dedicated battery pack to UHome storage unit.



- If the moisture penetrates the system (e.g., due to casing damage), please do not install or operate the system.
- Do not use wet hands to touch the system.
- Any behavior to change the functionality of the product without permission will cause fatal injury to the operator, third parties, and equipment. UHome is not responsible for these losses and warranty claims.
- To ensure property and personal safety, the batteries and inverter shall be well grounded.

	Caution!
	• Do not modify or tamper with storage unit and other components of
	the system.
Λ	Risk of injury by hoisting or falling system
$\underline{\langle \cdot \rangle}$	• Inverters and batteries are heavy and personal injury can be
Caution	caused if the inverter or battery is improperly lifted or dropped
	during transport or improper operation when attached or removed
	from walls. Lifting and moved the products shall be conducted by
	more than one person.
	Note !
	• Do not extend other brands of batteries at the battery port.
1-37	• Storage unit outputs AC power directly to the utility grid and the
	backup loads. Do not reverse output of these two AC terminals of
	the inverter.

2.2 Explanation of Symbols

This section explains all the symbols shown on the inverter and on the type label.

(6	CE mark. The inverter complies with the requirements of the applicable CE guild lines.
4	Dangerous electrical voltage The device is directly connected to public grid, thus all work to the battery shall only be carried out by qualified personnel.
	No open flames Do not place or install near flammable or explosive materials.
	Corrosive substance Keep the inverter away from corrosive substance.
	Attention Install the product out of reach of children

	Danger of hot surface
	The components inside the device will release a lot of heat during
	operation. Do not touch metal plate housing of the inverter during
	operating.
Λ	Danger.
\sum	Risk of electric shock!
	An error occurred
	Read the usage manual to troubleshoot problems
	This device SHALL NOT be dispessed of in residential wests
T	Places us to Obserter Oscer "Detters residential waste
	Please go to Chapter Seven "Battery maintenance for proper
	treatment.
	Description
	Kecyclable
,	

2.3 Emergency situation

Despite of its careful and professional protection design against any hazard results, damage of the battery may still occur. If a small amount of battery electrolyte is released due to a serious damage of the outer casing; or if the battery explodes due to not being treated timely after a fire breaks out nearby, and leaks out poisonous gases such as carbon monoxide, carbon dioxide etc., the following actions are recommended:

- 1) Eye contact: Rinse eyes with a large amount of running water and seek medical advice
- 2) Contact with skin: Wash the contacted area with soap thoroughly and seek medical advice
- 3) Inhalation: If you feel discomfort, dizziness or vomiting, seek medical advice immediately.
- 4) Use a FM-200 or Carbon Dioxide (CO₂) fire extinguishers to extinguish the fire if there is a fire in the area where the battery pack is installed. Wear a gas mask and avoid inhaling toxic gases and harmful substances produced by the fire.
- 5) Use an ABC fire extinguisher, if the fire is not caused by battery and not spread to it yet.

Warning!



- If a fire has just occurred, try to disconnect the battery circuit breaker and cut off the power supply first, but only if you can do so without endangering yourself.
- If the battery is on fire, do not attempt to extinguish the fire and evacuate the crowd immediately.

Potential danger of damaged battery:

Chemical Hazard: Despite of its careful and professional protection design against any hazard results, rupture of battery shall still occur due to mechanical damage, internal pressure etc., and may result in a leakage of battery electrolyte. The electrolyte is corrosive and flammable. When there is fire, the toxic gases produced will cause skin and eyes irritation, and discomfort after inhalation. Therefore:

- 1) Do not open damaged batteries.
- 2) Do not damage the battery again (shock, fall, trample, etc.).
- 3) Keep damaged batteries away from water (except to prevent an energy storage system from catching fire).
- 4) Do not expose the damaged battery to the sun to prevent internal heating of the battery.

Electrical hazard: The reason of fire and explosion accidents in lithium batteries is battery explosion. Here are the main factors of battery explosion:

- Short circuit of battery. Short circuit will generate high heat inside battery, resulting in partial electrolyte gasification, which will stretch the battery shell. The temperature reaching ignition point of internal material will lead to explosive combustion.
- 2) Overcharge of battery. Overcharge of battery may precipitate lithium metal. If the shell is broken, it will come into direct contact with the air, resulting in combustion. The electrolyte will be ignited at the same time, resulting in strong flame, rapid expansion of gas and explosion.

3 Introduction

3.1 Scope of application

UHome Hybrid Storage Unit has two PV inputs and is used in new installation systems.



In daytime, solar power supports the loads first while the surplus power will be stored by storage unit, to improve self-consumption rate.

In peak power price hours, power from storage unit supports the loads; while in valley power price hours, storage unit is charged by the grid. Finally, a balance could be realized.

In case of grid fault, storage unit will make sure no outage in the loads, achieving UPS function.

Storage unit has two parts, inverter and battery. Storage unit can have a capacity expansion according to user demands and the modular design of the slave device makes it easy to install wiring.



Quantity of Inverter	Quantity of Battery	System Capacity
1	1	5.12kWh
1	2	10.24kWh
1	3	15.36kWh
1	4	20.48kWh
1	5	25.6kWh
1	6	30.72kWh

3.2 Product Model Description

<u>UHome</u> - <u>3K0</u> L

1

2 3

- ① **UHome** is the name of All-In-One Storage Unit.
- ② **3K0** indicates the rated power of the hybrid inverter, such as 3.0K for 3kW.
- ③ L indicates that the system is a low-voltage system.

<u>ULB – 5120 MT</u>

1 2 3

- ① **ULB** is the name of the Battery Module section in the All-In-One Storage Unit.
- 2 **5120**:5.12kWh /**2560**:2.56kWh/**3580**:3.58kWh.
- ③ MT: Wall hanging.

3.3 Datasheet

Hybrid Inverter	UHome-3K0L	UHome-3K6L	UHome-4K0L
PV Input			
Max. PV Array Power [Wp]@STC	4500	5400	6000
Max. DC Input Voltage [V]		550	
MPPT Voltage Range [V]		80~500	
Rated DC Voltage [V]		360	
Start Voltage [V]		100	
Max. DC Input Current [A]		14/14	
Max. DC Short Circuit Current [A]		16/16	
Quantity of MPPT		2	
Battery Data			
Battery Type		LiFePO ₄	
Battery Capacity per Kit [kWh]		5.12	
Rated Voltage [V]		51.2	
Voltage range [V]		44.8-57.6	
Depth Of Discharge [DOD]		≤90%	
Max. Charging Power [W]	3000	3680	4000
Max. Charging Current [A]	60	72	80
Max. Discharging Current [A]	60	72	80
Scalability	Υ	es (up to 30.72kWh)	
Grid Data			_
Rated Output Power [W]	3000	3680	4000
Max. Continuable Output Power [VA]	3300	3680	4400
Rated Output Current [A]	13	16	17.4
Max. Output Current [A]	14.3	16	19.1
Rated Grid Voltage/Range [V] [1]	220, 230, 240, L+N+PE		
Rated Grid Frequency/Range [Hz] ^[1]	50/60		
Power factor [cos φ]	0.8 leading~0.8lagging		
THDi	< 3%		
AC Output [Back-up Mode]			
Max. Continuable Output Power [VA]	3000	3680	4000
Output Voltage [V]	220/230/240		
Max. Output Current [A]	13	16	17.4
Output Frequency [Hz]		50/60	
Max. Output Power [VA]	3300 ,60sec	4048 ,60sec	4400 ,60sec
General Data			
Communication Mode	Wi-Fi		
Operating Temperature Range	-30°C~+60°C		
Cooling Method	Natural Convection		
Altitude	4000m(>3000m power derating)		
Ambient Humidity	0-100% non-condensing		
Noise[dBA]		<25	
Ingress Protection	IP65		
Dimensions [H*W*D] [mm]	675*200*415 (Inverter) /675*200*365(Battery)		
Weight [kg]	34(Inverter)/53.6(Battery)		

[1] The AC voltage and frequency range may vary depending on specific country grid.

Hybrid Inverter	UHome-4K6L	UHome-5K0L	UHome-6K0L
PV Input		· · · ·	
Max. PV Array Power [Wp]@STC	6900	7500	9000
Max. DC Input Voltage [V]		550	
MPPT Voltage Range [V]		80~500	
Rated DC Voltage [V]		360	
Start Voltage [V]		100	
Max. DC Input Current [A]		14/14	
Max. DC Short Circuit Current [A]		16/16	
Quantity of MPPT		2	
Battery Data			
Battery Type		LiFePO ₄	
Battery Capacity per Kit [kWh]		5.12	
Rated Voltage [V]		51.2	
Voltage range [V]		44.8-57.6	
Depth Of Discharge [DOD]		≤90%	
Max. Charging Power [W]	4600	5000	6000 ^[2]
Max. Charging Current [A]	92	100	120 ^[2]
Max. Discharging Current [A]	92	100	120 [2]
Scalability		Yes (up to 30.72kWh))
Grid Data			
Rated Output Power [W]	4600	5000	6000
Max. Continuable Output Power [VA]	4600	5000	6600
Rated Output Current [A]	20	21.7	26
Max. Output Current [A]	20	21.7	28.7
Rated Grid Voltage/Range [V] ^[1]	220, 230, 240, L+N+PE		
Rated Frequency/Range [Hz] ^[1]	50/ 60		
Power factor [cos φ]	0.8 leading~0.8lagging		
THDi	< 3%		
AC Output [Back-up Mode]			
Max. Continuable Output Power [VA]	4600	5000	6000 ^[2]
Output Voltage [V] ^[1]		220/230/240	
Max. Output Current [A]	20	21.7	26 ^[2]
Output Frequency [Hz] ^[1]		50/60	
Max. Output Power [VA]	5060 ,60sec	5500 ,60sec	6600 ,60sec
General Data			
Communication Mode		Wi-Fi	
Operating Temperature Range	-30~+60 ℃		
Cooling Method	Natural Convection		
Altitude	4000m(>3000m power derating)		
Ambient Humidity	0-100% non-condensing		
Noise[dBA]	<25		
Ingress Protection	IP65		
Dimensions [H*W*D] [mm]	675*200*415 (Inverter) /675*200*365(Battery)		
Weight [kg]	34(Inverter)/53.6(Battery)		

[1] The AC voltage and frequency range may vary depending on specific country grid.

[2] Storage unit needs at least two batteries to reach >6000W output.

Hybrid Inverter	UHome-8K0L
PV Input	
Max. PV Array Power [Wp]@STC	12000
Max. DC Input Voltage [V]	550
MPPT Voltage Range [V]	80~500
Rated DC Voltage [V]	360
Start Voltage [V]	100
Max. DC Input Current [A]	14/28
Max. DC Short Circuit Current [A]	16/32
Quantity of MPPT	2
Battery Data	
Battery Type	LiFePO4
Battery Capacity per Kit [kWh]	5.12
Rated Voltage [V]	51.2
Voltage range [V]	44.8-57.6
Depth Of Discharge [DOD]	≤90%
Max. Charging Power [W]	8000 [2]
Max. Charging Current [A]	160 [2]
Max. Discharging Current [A]	160 [2]
Scalability	Yes (up to 30.72kWh)
Grid Data	
Rated Output Power [W]	8000
Max. Continuable Output Power [VA]	8800
Rated Output Current [A]	35
Max. Output Current [A]	38.3
Rated Grid Voltage/Range [V] ^[1]	220, 230, 240, L+N+PE
Rated Grid Frequency/Range [Hz] ^[1]	50/60
Power factor [cos φ]	0.8 leading~0.8lagging
THDi	< 3%
AC Output [Back-up Mode]	
Max. Continuable Output Power [VA]	8000 [2]
Output Voltage [V] ^[1]	220/230/240
Max. Output Current [A]	35 [2]
Output Frequency [Hz] ^[1]	50/60
Max. Output Power [VA]	9600 ,60sec
General Data	
Communication Mode	Wi-Fi
Operating Temperature Range	-30~+60 ℃
Cooling Method	Natural Convection
Altitude	4000m(>3000m power derating)
Ambient Humidity	0-100% non-condensing
Noise[dBA]	<25
Ingress Protection	IP65
Dimensions [H*W*D][mm]	675*200*415 (Inverter) /675*200*365(Battery)
Weight [kg]	34(Inverter)/53.6(Battery)

[1] The AC voltage and frequency range may vary depending on specific country grid.

[2] Storage unit needs at least two batteries to reach >6000W output.

Battery Module	ULB-5120MT
Electrical Parameter	
Battery Type	LiFePO ₄
Battery Capacity per Kit [Wh]	5120
Usable Energy [Wh]	4600
Rated Voltage [V]	51.2
Voltage range [V]	44.8-57.6
Max. Charging and Discharging Rate	1C
Depth Of Discharge [DOD]	≤90%
Cycle Life(25°C,0.5C)	≥6000 times,80% Capacity retention
General Data	
Communication Mode	RS485/CAN2.0
Operating Temperature Range	0~50°C (Charge)/-10~50°C(Discharge)
Storage Temperature Range	-15°C~60°C
Cooling Method	Natural Convection
Altitude	<2000m
Ambient Humidity	0-100% non-condensing
Noise[dBA]	<25
Ingress Protection	IP65
Dimensions [H*W*D][mm]	675*200*365
Weight [kg]	53.6

4 Installation Instructions

4.1 Safety Tips

Danger!

- Potential fires and electric shocks that are life threatening.
- Do not place any flammable or explosive materials beside storage unit.
- Equipment connected to high-voltage power generation equipment must be performed by qualified personnel in compliance with national and local standards and regulations.

Note!

- The pollution level applicable to storage unit is Class II.
- Inappropriate or inconsistent installation environment can shorten the life of storage unit.
- Do not install storage unit directly by exposing it under strong sunlight.
- Please do not install in damp places.
- The installation location must be well ventilated.
- Storage unit (hereinafter also referred to as the master device) can be used with one battery. If the battery capacity needs to be expanded, please use ULB-5120MT (slave device), and maximum 4 batteries are supported for the whole system.

4.2 Packing List

Hybrid Inverter



No por			
2*PV+ input terminal; 2*Secured Metal terminals to PV+ input power cables	2*PV- input terminal; 2*Secured Metal terminals to PV- input power cables	1* Waterproof aviation male pin plug	1* Waterproof aviation female pin plug
1*Waterproof terminal	2* Tube terminal (red)	2* Tube terminal (black)	2* Tube terminal (yellow)
	P	-	
2*Fixed support rack	4*Round head screws M3*5	4*SEM screw M4*10	2*Expansion screw M6
	QUALIFIED CERTIFICATE		
1* Allen wrench D- 3mm L type	1*Qualified Certificate	1*Pac	cking List

Storage Battery

			P
1 * Battery	2*Fixed support rack	2*Expansion screw M6	4*Round head screws M3*5

Ŷ		01110	QUALIFIED CERTIFICATE INSPECTOR	
4*SEM screw M4*10	4*Guide Pin	1*Grounding Cable	1*Qualified Certificate	
		\bigcirc	- JB	
1*Right side cover	1*Left side cover	1*Cable grommet	8*Countersunk screw	
1*Packing List				

Base

		01110
1 * Battery	4*Guide Pin	1*Grounding Cable
QUALIFIED CERTIFICATE		đe eos
1*Qualified Certificate	1*Packing List	1* External positive connection wire (The length is determined according to the number of stacked batteries)

4.3 Determine the installation method and location

Inverter dimension (mm) :



Battery dimension (mm) :



Base dimension (mm) :



Storage unit is cooled by natural wind convection. It is recommended to install in indoors or sheltered areas to avoid direct sunlight, rain and snow.



Please ensure that the air at the installation point is circulated. Bad air ventilation will affect the working performance of internal electronic components and shorten the service life of storage unit.



The following sites are not allowed for installation:

- within 600mm of any exit.
- within 600mm of any vertical side of a window or building ventilation that ventilates a habitable room.
- in celling spaces.
- in wall cavities or under stairways.
- on roofs, except for were specially deemed suitable.
- under access walkways.
- sites where the freezing point is reached, like garages, carports or other places.
- places with plenty of salt.
- flooded areas.
- within 600mm of any hot water unit, air conditioning unit or any other appliance associated with the pre-assembled integrated battery energy storage system.

20

4.4 Preparations before installation

Step 1: Take out the inverter, battery and base from the packing box.

Step 2: Preparation before base installation:

- Use screwdriver to loosen the 4 screws on the side of the terminal and remove the cover.
- ② Install the 4 positioning pins in the holes at the four corners of the base, and tighten them with a flathead screwdriver.



Step 3: Preparations before battery installation:

- ① Use screwdriver to loosen the cover screws on both sides.
- ② Pass the upside-down hanging ear through the mounting hole of the chassis, and fix it with screws. It needs to be adjusted later, so it does not need to be tightened.
- ③ Install the 4 positioning pins in the holes at the four corners of the battery case, and tighten them with a flathead screwdriver.



Step 4: Preparations before inverter installation:

- ① Use screwdriver to loosen the 4 fixing screws on the side cover and
- remove the left cover.
 Pass the upside-down hanging ear through the mounting hole of the chassis, and fix it with screws. It needs to be adjusted later, so it does not need to be tightened.



4.5 Installation steps for storage unit



Step 1: Choose the installation location, place the base, adjust it to horizontal, and the base is 10~20mm away from the wall.



Step 2: Stack the battery module-inverter in sequence.



Step 3: Use a marker pen to draw a line in the hole of the wall fixture to determine the position of the screw hole.



Step 4: Take down the inverter-battery box in sequence.

Step 5: Use a percussion drill to drill holes marked in Step 3 and drive in expansion screws.

Step 6: Stack the battery module-inverter in sequence, tighten the cascading fixing screws, fix the screws and wall fixing parts on the wall with a wrench,

adjust the fixing bracket screws of the chassis, and adjust the distance between the chassis and the wall to an appropriate distance (10~20mm) rear locking screw.





5 Electrical Connections

5.1 Electrical Interface Description

5.1.1 Inverter interface description



Object	Description	Object	Description
1	WiFi Port	7	PV Switch
2	CT Port	8	Battery Switch
3	DRM Port	9	Battery signal port
4	Load Connection	10	Battery Connection
5	Grid Connection	11	Grounding screw
6	PV INPUT port	/	1

5.1.2 Battery interface description



Object	Description	Object	Description
1	Service port	3	ADD port
2	Power button	4	Grounding screw

5.1.3 Base interface description



Object	Description	Object	Description
1	Battery + connection port	2	Grounding

5.2 System Wiring Schematic



5.3 Battery Wiring

Warning!

- The Batteries are paralleled to the inverter.
- Ensure Battery switch is off during installation to avoid the risk of short circuit caused by wrong operation during battery wiring.
- Do not connect one Expansion Battery to two different inverter devices at the same time

5.3.1 Battery wiring (Battery does not expand)

Step 1: Take out the wire harness, plug it into the socket of the base, connect the positive socket of the inverter, hear a "click" sound, the installation is correct, arrange the cables into the edge groove.



Step 2: Set the DIP switch of each battery.



DIP switch configuration can be found below:

Configuration	Battery	Battery	Battery	Battery	Battery	Battery
g	(No.1)	(No.2)	(No.3)	(No.4)	(No.5)	(No.6)
1*Inverter 1* Battery	ON DIP	/	1	/	/	/
1*Inverter 2* Battery	DP N	ON DIP	/	/	/	/
1*Inverter 3* Battery	D N		ON DIP	/	/	/
1*Inverter 4* Battery	ON DIP	ON DIP	ON DIP	ON DIP	/	/
1*Inverter 5* Battery	ON DIP	/				
1*Inverter 6* Battery	ON DIP	ON DIP		ON DIP	ON DIP	ON DIP

5.3.2 Grounding wire connection

Take out the grounding wire and screw (M4-10), and install it to the corresponding position with a screwdriver.



5.3.3 Side protection cover installation

After connecting the wires, find the corresponding side cover, place it in a suitable position, and screw on the fixing screws with a screwdriver;



5.4 PV Input Wiring



Step 1: Prepare PV positive and negative power cables.



Step 2: Insert the crimped photovoltaic positive and negative power cable into the corresponding photovoltaic connector.



Step 3: Insert the positive and negative connectors into the corresponding PV region of the HSU unit until a click is heard.



Warning!

- Make sure that the DC voltage of each PV string is less than 550V and the polarity of PV cables are correct.
- Make sure that the DC switch should be turned off.

5.5 Grid/Load Wiring



Warning!

Turn off the Battery Switch and external AC breaker after unpacking in any cases before and during wiring in case of electric shock.

Please be cautious when unplug battery switch cable during dismantling.

Step 1:

① Choose the right cable.

Cable type	Conductor cross-sectional area (mm ²)	
	Outside diameter (mm ²)	Conductor core section (mm ²)
10 AWG	5.5-8.0	4.0-6.0

② Peel off the cable insulation sleeve for 16 mm, as shown in Figure:



Step 2: Take out the plug accessories and disassemble the plug according to the picture.

Unscrew the 3 clamp sleeve, press the "PUSH" button on the 2 shell, and pop out the 1 terminal block.



Step 3: Pass the cable through the plug part in the order of 4-3-2-1, loosen the terminal screw, insert the cable into the corresponding terminal block and lock the screw.

Cable	Number
L	1
Ν	2
PE	3





Step 4: Assemble the plug according to the picture;

 Press and hold the "PUSH" button on the shell, push the connected cable seat into the shell, and when you hear a "click", the installation is complete.



① Lock the clamping sleeve into the housing, lock it.



② Lock the waterproof nut on the clamp sleeve.



Step 5: Insert the plug into the corresponding socket, when you hear a "click", the installation is complete.



5.6 EV Charging wiring

The UHome system reserves an EV interface, which can be used with a portable AC charging cable to charge the electric car to form a home electric car charging system. The maximum EV power is \leq 3.5KW, and the total power of EV+AC load cannot exceed the load output power of the inverter.



5.7 DRM Port Description

To comply with Australian and New Zealand safety requirements, the DRMs terminals should be connected. A RJ45 plug is being used as the inverter DRED connection.



Object	Corresponding Pins	Requirement
DRM0	5 & 6	The inverter is on standby mode
DRM1	1 & 6	The inverter is not consuming power
DRM2	2 & 6	The inverter is consuming less than 50% of rated power
DRM3	3 & 6	The inverter is consuming less than 75% of rated power AND source reactive power if capable
DRM4	4 & 6	The inverter is consuming 100% of rated power (Subject to constrains from other active DRMs)
DRM5	1 & 5	The inverter is not generating power
DRM6	2 & 5	The inverter is generating less than 50% of the rated power
DRM7	3 & 5	The inverter is generating less than 75% of the rated power AND sink reactive power if capable
DRM8	4 & 5	The inverter is generating 100% of rated power (Subject to constrains from other active DRMs)

5.8 CT Installation

CT solution is offered for sampling data of grid side as standard solution.

Please install CT with instructions as below:

- 1) Lead the Live line through the CT.
- 2) Tighten up the CT buckles.

- 3) Remove the cover of CT port on the right side of inverter.
- 4) Connect RJ45 plug of the CT to the CT port.



CT direction shall point to the grid side. Please notice the CT direction. The CT should be installed near the grid.



5.9 External AC Circuit Breaker and Residual Current

Device

Please install a circuit breaker to ensure the inverter is able to disconnect from grid safely. The inverter is integrated with a RCMU; however, an external RCD is needed to protect the system from tripping, either type A or type B RCD are compatible with the inverter.

The integrated leakage current detector of inverter is able to detect the real time external current leakage. When a leakage current detected exceeds the limitation, the inverter will be disconnected from grid quickly, if an external residual current device is connected, the action current should be 30mA or higher.

5.10 Battery expansion

Refer to 5.3.1 to connect the UHome system and another set of expansion batteries.



Use the accessory harness to connect two sets of batteries, the battery packs are connected in parallel, BAT + connects to BAT +, BAT – connects to BAT -, COM connects to COM.



6 Local Configuration

6.1 Local Interface Introduction

UHome Storage Unit has a touch screen on the front of inverter.

⟨]	Home Page
ÊN	Detail Info Page
\triangle	Fault Page
\mathcal{P}	Statistics Page
ବ୍ରି	Setting Page

6.2 Home Page

This page shows the total PV input power, AC grid power, battery power and SOC, load power.



6.3 Detail Info Page

6.3.1 PV Info Page (only Hybrid)

This page shows the voltage, current and power of two different PV inputs.

æ	(\underline{A})	G	\$		
	PV1			PV1	
Volt		V	Vo	lt	V
Current		А	Cu	rrent	А
Power		w	Po	wer	W

6.3.2 Grid Info Page

This page shows the voltage, current, power and frequency of AC grid.



6.3.3 Load Info Page

This page shows the voltage, current and power of the loads.

	(\mathbf{A})	ŝ		
Volt	V			
Current	А			
Power	W			

6.3.4 Battery Info Page

This page shows the voltage, SOC, temperature, current, power and charging/discharging limit of the battery.

Volt V SOC % Temp % Current A Max Charge Current A Power W Max Discharge Current A		(\mathbf{A})				
Current A Max Charge Current A Power W Max Discharge Current A	Volt	V	SOC	%	Temp	°C
Power W Max Discharge Current A	Current	А	Max Charge (Current		А
	Power	w	Max Discharg	e Current		A

Battery LED indication status

6.3.5 Inverter Info Page

This page shows the BUS voltage, internal temperature of the inverter.

	(\mathbf{A})			
S_BUS_Volt	V	1		
N_BUS_Volt	V	1		
DCDC_Temp	°	2		
Inv_Temp	°(0		
Env_Temp	°	2		
				5

6.4 Fault Page

This page shows the real-time fault alarm and fault history of the storage unit.

Real-time Alarm	History	
Real-time Alarm	History	

6.5 Statistics Page

(\mathbf{A})	(kWh)	Day	Month	Year	Total	
	Charge					
	Discharge					
	(kWh)	Day	Month	Year	Total	
	Charge					
	Discharge					
		Nex	kt	\supset		*
	(kWh)	Day	Month	Year	Total	
	(kWh) Production	Day	Month	Year	Total	
	(kWh) Production (kWh)	Day Day	Month	Year Year	Total	

These two pages show statistics info of Grid, Battery, PV and Load.

6.6 Setting Page

6.6.1 Brightness Setting Page

This page shows the brightness setting and screen off time setting.

🗘 Brightness 📩 Inverter	(i) Version	🗙 Clear
)	Ċ,
Screen off time :	S	
		<u>_</u>

The value range is shown as below:

ltem	Description	Range
Brightness	the brightness of screen	Min - Max
Screen off time	the time to turn off the screen	5 – 500 s

6.6.2 Inverter Setting Page

This page needs a password. The default password is "12345". Installer can change it in this menu.

7 8 9 ,	
4 5 6 ← 1 2 3	
0 · OK	

1) System Setting

This page shows the work mode setting, PV input setting, EPS Enable setting,

battery awaken setting, zero export setting, Arc detection setting, date setting and time setting.

لَي Brightness	Linverter	(i) Version	☆ Clear	
System Setting	Work Mode PV Input			6
Batt Setting Run Setting	EPS Enable	Batt Av	vaken	
Grid Setting	Zero Export Date/Time	Arc Dete	ection	5

The value range is shown as below:

ltem	Description	Default Setting	Range
Work Mode	Work mode of the storage	Work mode of the storage unit Self Consume	
	unit		
D\/ Input	PV input mode of the storage	Indonondont	Independent Dependent
r v input	unit	Independent	② Parallel③ CV (only factory test)
EPS Enable	Turn on/off the EPS output	OFF	ON / OFF
Batt Awaken	Wake up the battery in some special time	OFF	ON / OFF
Zero Export	Limit the export power to the public power grid	OFF	ON / OFF
Arc Detection	Turn on/off the Arc detection of PV	OFF	ON / OFF
Date	Date	-	20000101 – 20991231
Time	Time	-	000000 – 235959
Password	Reset the password	12345	10000 - 65535



Self Consume Mode:



Peak Shift Mode:



Channa Tina 1]	
Charge Time 1:		Disharge Time 1:
Start	End	Start End
Charge Time 2:		Discharge Time 2:
Start	End	Start End
Charge Time 3:		Disharge Time 3:
Start	End	Start Fad

ltem	Description	Range
Start	Start time of charge/discharge	0000 – 2359
End	End time of charge/discharge	0000 – 2359



The "Start" and "End" should be set with 4 numbers. First 2 numbers are "hour". Second 2 numbers are "minute". "1201" means 12:01

Bat Priority Mode:



2) Batt Setting

This page shows the battery type setting, on-grid DOD setting, off-grid DOD setting, charge current setting, Hysteresis setting, battery communication setting and grid rate setting.

لُبُ Brightness	Inverter	(j) Version	🛠 Clear
	Batt Type		▼
System Setting	On Grid DOD	Off	Grid DOD
Bun Setting	Charge Curr	H	lysteresis
Grid Setting	Batt-Comm		•
ond setting	Grid-Rate		▼

The value range is shown as below:

ltem	Description	Default Setting	Range
Batt Type	Battery type of the storage unit	Lithium	 DC Source (only factory test) Lead-Acid (only service test) Lithium
On-grid DOD	Depth of discharge in the on-grid mode	90	10 - 90
Off-grid DOD	Depth of discharge in the off-grid mode	10	10 - 90
Charge-Curr	Current limit of charge	100	1 - 170
Hysteresis	Hysteresis of the battery DoD	20	10 - 90
Batt-Comm	Battery communication type of the storage unit	CAN	 RS485 CAN
Grid-Rate	type of the AC power grid	220V Single	 220 V Single 120V/240V 120V/208V 120V Single

Note !



- The "Batt Type" should be set as "Lithium". Don't choose others during the installation.
- The "Batt Comm" should be set as "CAN". Don't choose others during the installation.

3) Runing Setting

This page shows the react mode setting, grid power setting, discharge power setting, grid voltage setting, grid frequency setting and grid standard setting.

🗘 Brightness	Lucation Inverter	() Version	☆ c	lear
	React Mode			
System Setting	Grid Power		Disc Power	
Batt Setting	Grid Voltage(V):	Low	High	
Run Setting	Grid Freq(HZ): l	_ow	High	
Grid Setting	Grid Std			5

The value range is shown as below:

ltem	Description	Default Setting	Range
React Mode	The react mode of the storage unit	Power Factor	 Power Factor React Power Qu Wave Qp Wave
Grid Power	export power to the AC power grid	100	0 - 100
Disc Power	Discharge power of the battery	100	0 - 100
Grid Voltage (Low)		176.0	150.0 – 220.0
Grid Voltage (High)	Change the protection	270.0	240.0 – 280.0
Grid Frequency (Low)	the grid standard	42.00	40.00 – 70.00
Grid Frequency (High)		58.00	40.00 – 70.00
Grid Std	grid standard for different counties	CN	Shown as below



The Grid Standard is shown as below and it will keep updating with the certificate testing.



4) Grid Setting

This page shows the voltage reset setting, frequency reset setting, leak current setting, active island setting and insulation detection setting.

Brightness	- Inverter	(i) Version	•	✿ Clear	
	PWR Volt Res		Leak (Cureent	
System Setting	PWR Freq Res		Active	e Island	
Batt Setting	PFC Volt Res				
Grid Setting	PFC Freq Res				
	Insulation Detect	ion			٢

Item	Description	Default Setting	Range
PWR-Volt Res		ON	ON / OFF
PWR-Freq Res		ON	ON / OFF
PFC-Volt Res	Turn on off the	ON	ON / OFF
PFC-Freq Res		ON	ON / OFF
Leak Current	protect setting	ON	ON / OFF
Active Island		ON	ON / OFF
Insulation Detection		ON	ON / OFF

6.6.3 Version Page

This page shows the version and serial number of the storage unit.

Brightness	- Inverter	(i) Version	숨 Clear	
	LCD :			
	ARM :			
	DSP:			
	SN :			
				<u>_</u>

6.6.4 Clear Page

This page needs a password. The default password is "12345". Installer can change it in the inverter setting.

7 8 9 ,	
4 5 6 ←	
1 2 3 _{OK}	
0 ·	

This page shows the clear options of the storage.

i Version 🛠 Clear
Factory Reset Clear His
lear Arc Alarm
lear Arc Alarm



6.7 Start up the System

The system shall be turned ON in the correct sequence as follows:

1) Turn ON the BAT switch at the right side of the inverter.

- Press power button at the right side of the batteries to turn on batteries, the order should be Battery No.4> Battery No.3> Battery No.2> Battery No.1; Observe the status light on the front of the battery.
- 3) Wait for 30s and observe the LCD on the front of inverter to check the running status.
- 4) Turn ON the PV switch at the left side of the inverter.
- 5) Turn on external AC switch.
- 6) If the system is running normal, please do commission configuration. If the system is not work normally, please re-check the wiring and setting until the system runs normal.
- 7) Set the details on the local screen.

Note!



The start-up procedure for the system should be: Inverter BAT switch >> Battery No. 4>> Battery No. 3>> Battery No.2>> Battery No.1 >>Inverter PV switch (PV not powered) >> External AC switch.

6.8 Shut Down the System

System shall be turned OFF in the correct sequence as follows:

- 1) Turn off the external grid AC switch.
- 2) Turn off the PV switch at the left side of the inverter.
- 3) Press the POWER button on the right side of the battery. the order should be Battery No.4> Battery No.3> Battery No.2> Battery No.1;
- 4) Turn OFF the Battery switch on the right side of the inverter.

Note!

1

 The procedure for turning off the system will be External AC switch >> Inverter PV switch (only Hybrid) >> Battery No.4>> Battery No.3>> Battery No.2>> Battery No.1>> Inverter BAT switch.

6.9 LED indication

6.9.1 Bat LED

LED status					
Potton Statua	Protection, alarm	RUN	ALM	Description	
Dattery Status	normal	Green	Red	/	
Off	/	Off	Off	All off	
	Normal		0	No charging or	
On	normai	FIASIT I	Oli	discharging	
OII	Warning Flash 1 Flash	Elach 2	PACK low		
	vvarning	FIASIT I	FIASIT 3	voltage	
	Normal	ON	Off	/	
	Warning	ON	Flash 3	/	
Charge	Over Charge	On	Off		
	Over	0"	On	Stop charging	
	Temp/Current,Failure	Oli			
	Normal	Flash 3	Off	/	
	Warning	Flash 3	Flash 3	/	
Discharge	Over Discharge	Off	Off		
	Over	Off	On	Stop discharging	
	Temp/Current,Failure	Oli	On		
Foiluro	1	Off	On	Stop charging	
гание	/		UI	and discharging	

Flash description:

Flash 1: 0.25s on/3.75s off

Flash 2: 0.5s on /0.5s off

Flash 3: 0.5s on,1.5s off

6.9.2 System status indicator

Work Mode	Status
Alarm or Fault	Red light keeps on
Normal	Green light slow flashing
Power off	Light off
BAT Low capacity/ Bat Under	Yellow light slow flashing
Communication failure	White light keeps on
Standby	Light off

7 Fault Codes and Common troubleshooting

Content	Codes	Explanation	Solution
Over Discharge Current	001	 If work in the off-grid mode, the load is higher than inverter power. The discharge current limit is too low. If install only one battery, the inverter power is higher than 5kW. 	 If work in the off-grid mode, check the off-grid load and make sure it is lower than the inverter output power. Check the discharge current limit and set a higher value. If install only one battery, try to install more batteries. If the problem still exists, contact manufacturer.
Over Load	002	If work in the off-grid mode, the load is too high.	 If work in the off-grid mode, check the off-grid load and make sure it is lower than the inverter output power and battery power. If the load is inductive load, wait for several minutes and check if the problem still exists. If the problem still exists, contact manufacturer.
Batt. Disconnected	003	 Battery switch is turned off. Battery button is turned off. Battery cables are disconnected. Battery fuse is disconnected. 	 Check the battery switch and turn on it. Check the battery button and turn on it. Check the battery cables. Check the battery fuse. If the problem still exists, contact manufacturer.
Batt. Under Capacity	004	Battery capacity is low and the battery voltage is low.	 Charge the battery and keep the capacity higher than 20%. If the problem still exists, contact manufacturer.
Batt. Low Capacity	005	Battery capacity is low.	1, Charge the battery and keep the capacity higher than (SOC > 100%-DOD+ Hysteresis). 2, If the problem still exists, contact manufacturer.
batt. High Volt	006	1, Battery is damaged. 2, Battery sampling is damaged.	 Measure the voltage and check if it is normal. If the problem still exists, contact manufacturer.
Grid Low Volt	007	Grid voltage is abnormal.	1, Check if the power grid is normal. 2, Check if the country is set correctly
Grid High Volt	008		3, Check if the voltage range is set correctly4, If the problem still exists, contact manufacturer.
Grid Low Freq.	009		1, Check if the power grid is normal. 2, Check if the country is set correctly
Grid High Freq.	010	Gnd Frequency is abnormal.	3, Check if the frequency range is set correctly4, If the problem still exists, contact manufacturer.
BUS Low Volt	014	BUS voltage is lower than normal.	Restart the system. If the problem still exists, contact manufacturer.
BUS High Volt	015	BUS voltage is over maximum value.	 Check if the PV input voltage is higher than limit. Check if the battery is too high Restart the system. If the problem still exists, contact manufacturer.
Inv. Over Current	016	1, If work in the off-grid mode, the load is too high. 2, If work in the off-grid mode, the RCD load is too high. (For example, air- conditioning)	 Check the load and make sure it is lower than the inverter output power. Restart the system. If the problem still exists, contact manufacturer.

Content	Codes	Explanation	Solution
Over Charge Current	017	1, The battery charge limit is too high. 2, If install only one battery, the inverter charge power is higher than 5kW.	 Check if the inverter charge limit is set correctly. If install only one battery, try to install more batteries. If the problem still exists, contact manufacturer.
Inv. Under Volt	019		If the problem still exists, contact manufacturer.
Inv. Over Volt	020	INV voltage is abnormal.	
Inv. Abnormality Freq.	021	INV frequency is abnormal.	If the problem still exists, contact manufacturer.
IGBT High Temp.	022	Bad heat dissipation of inverter.	 Check the installation position and keep a good heat dissipation of inverter. If the problem still exists, contact manufacturer.
Batt. Over Temp.	024	1, Bad heat dissipation of battery. 2, Battery keeps discharge within a high power.	 Check the installation position and keep a good heat dissipation of battery. If in the Peak Shift mode, change a shorter discharge time. If in the Self Consume mode, install more batteries. If the problem still exists, contact manufacturer.
Batt. Under Temp.	025	Battery temperature is lower than the allowed value.	 Check if the environment temperature is too low. Use small load first until the warning disappear. If the problem still exists, contact manufacturer.
BMS Comm. Fail	028	 Battery communication cable is damaged, Battery address is set incorrectly. Battery button is turned off. 	 Check if the battery button is turned on. Check if the battery communication cable is normal. Check if the battery address is set correctly. If the problem still exists, contact manufacturer.
Fan Fail	029	Fan fail.	1, If the problem still exists, contact manufacturer.
Grid Over Load	030	The bypass load in the grid side is too high.	1, Check if the off-grid load is too high. 2, If the problem still exists, contact manufacturer.
BUS Soft Start Fail	033	The inverter may be damaged.	1, Restart the system. If the problem still exists, contact manufacturer.
Inv. Soft Start Fail	034		
BUS Short Circuit	035		
Inv. Short Circuit	036		
Fan Locked Fail	037	Fan fault.	1, If the problem still exists, contact manufacturer.
PV Insulation Low	038	PV Low insulation impedance.	 Check if the PV cable is damaged. When it is raining, keep observing and check if the problem still exists when it is sunny. If the problem still exists when it is sunny, contact manufacturer.

Content	Codes	Explanation	Solution
BUS Relay Fault	039	The inverter may be damaged.	1, Restart the system. If the problem still exists, contact manufacturer.
Grid Relay Fault	040		
EPS Relay Fault	041		
GFCI Fault	042		
PV Input Short Circuit	044		
Bypass Relay Fault	045		
System Fault	046		
Inv. Current DC Over	047		
Inv. Volt DC Over	048		
Device Comm. Fail	049	The indicator board fails to communic ate with the display	1. Restart. 2. Contact us

8 Battery Maintenance

8.1 Transportation

Lithium batteries are dangerous goods. Passed the test of UN38.3, this product meets the transportation requirements for dangerous goods for lithium batteries. After the installation of the battery on site, the original packaging (contains the lithium battery identification) should be kept. When the battery needs to be returned to the factory for repair, please pack the battery with the original packaging to reduce unnecessary trouble.

8.2 Storage

After purchasing the battery, please store it with following instructions:

- 1) Please store it in a dry and ventilated environment, keep it away from heat sources.
- Please keep it in an environment with storage temperature as -20 ° C ~ 50 ° C, humidity <85% RH.
- 3) For long-term storage (>3 months), please put it in an environment with a temperature of 18 ° C to 28 ° C and a humidity of < 85% RH.
- 4) The battery should be stored in accordance with the storage requirements mentioned above, and the battery should be installed within 6 months since delivered from the factory and used with compatible inverters.

Note!

[-`

- The battery remains 30% power when it is sent from the factory.
- The longer the battery is stored, the DOD value is getting bigger. When the battery remaining voltage fails to reach the startup voltage requirement, the battery may be damaged.

The battery cannot be disposed of as household refuse. When the service life of the battery reaches to the limit, it is not required to return it to the dealer or UHome, but it must be recycled to the special waste lithium battery recycling station in the area.

8.3 Cleanliness

Clean the enclosure lid, LCD of the inverter with moistened cloth with clear water only. Do not use any cleaning agents as it may damage the components.



UPOWER ELECTRIC CO.,LTD

Add: 4F-A Block,No.62,Yinhe Road,Longgang District, Shenzhen,Guangdong,China Email: info@ucanpower.com

Web: www.ucanpower.com